

INSTRUCTIONS:

- 1. Strip about three inches of the outer jacket (if applicable) of the speaker wire with an appropriate stripping tool or utility knife. (Be careful not to cut into inner insulated conductors).**
- 2. Remove approximately 3/8" of insulation from the copper wire conductor. (Twist the ends on the conductor so all bare wires are close together.)**
- 3. Match polarity Positive conductor with red connector & Negative conductor with black connector.**
- 4. Insert the binding post inserts into two unused Datacom wall plate ports (holes) from the back of the wall plate.**
- 5. Mount the wall plate to a standard electrical J-box or low voltage mounting bracket.**