




Part No. 280319

USB over Single Category 5e Cable Extender

Installation Guide

1. Connect the (Transmitter side) USB Type-A Male connector to the host computer.
2. Connect the RJ45 Category 5e cable (up to 132 ft (40 meters)) between the Transmitter and the Receiver.
3. Connect the USB Device to the (Receiver side) USB Type A Female connector.



1. Troubleshooting

If you are having trouble with the extension:

1. Try re-plugging each connector.
2. Confirm the two host computer's USB ports are functional.
3. Ensure the USB device is turned ON.
4. Test and confirm the RJ45 Category 5e Patch cable is functional.