

1x4 Toslink Audio Splitter

DEAR CUSTOMER

Thank you for purchasing this product. For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

FEATURES:

- Allows 1 Optical/Toslink source to be distributed to up to 4 Optical/Toslink outputs
- Compact size, plug and play unit
- Eliminates the need of higher cost equipment
- Supports fiber optic S/PDIF and AES3 format of digital audio signal
- Amplifies digital audio signal to extend transmission distance
- Dimensions: 2.5" W x .875" H x 1.625" D

SPECIFICATIONS:

Input	1xOptical Fiber (TOSLINK connector)
Output	4xOptical Fiber (TOSLINK connector)
Sampling rate.....	32, 44.1, 48, 96 and 192KHz
SNR	98 dB
Separation	92db(1KHz)
Frequency response	20HZ-20KHZ ±0.5db
Weight (Net)	60g
Operating Temperature.....	-10 to +70 Degrees C
Operating Humidity	10% to 85 % RH (no condensation)
Storage Temperature	-10to +70 Degrees C
Storage Humidity	5% to 90 % RH (no condensation)
External Power Supply	5V DC@1A
Power Consumption	0.5 watts (max)
Converter Unit.....	FCC,CE,UL
Power Supply	UL,CE,FCC

CONNECT AND OPERATE

1. Connect a digital audio source such as a Blu-Ray Player, game console, media player, Cable or Satellite Receiver, etc. to the Toslink input using digital optical cables.
2. Connect digital audio output(s) such as an A/V Receiver to the Toslink output(s) on the unit using digital optical cables.
3. For power, plug in the Splitter with the included power supply.
4. Power on the source, followed by the output component(s)

PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

1. Main unit (280584)
2. 5V DC Power Supply
3. User's Manual

